








Netti Dynamic System – Gas cylinder for FREE solution 2016



A description on how to adjust the Free-gas cylinder is found under the individual chair model.





It contains also a short description how to adjust the FREE-Gas cylinder at the front and back part of the frame for CED and BASE.

For Netti III and Netti Mobile it is only to adjust the Gas cylinder at the front part.

- 1. Netti III Cylinder adjustment in the front of the chair
- 2. CED and BASE Cylinder adjustment in the front and back of the chair -
- 3. Netti Mobile Cylinder adjustment in the front of the chair


Be aware that a shorter seat depth require a short NDS-Seat plate.






CED and BASE - Cylinder adjustment - NDS-FREE solution

Adjusted set depth at back hinge	Front gas cylinder attachment must always be in the middle hole = B (see drawing)	Adjusted seat depth at cylinder hinge	Starting angle	
42,5	В	42,5	92°	
42,5	В	45	83°	
42,5	В	47,5	not possible	
42,5	В	50	not possible	
45	В	45	92°	
45	В	47,5	83°	
45	В	42,5	104°	
45	В	50	not possible	
47,5	В	47,5	92°	
47,5	В	50	83°	
47,5	В	45	104°	
47,5	В	42,5	not possible	
50	В	50	92°	
50	В	47,5	104°	
50	В	42,5	not possible	
50	В	45	not possible	



Gas cylinder attachment at front (A - B - C)



When working with a CED/S (SD 37,5 to 45 cm) you can follow the same scheme

Union in the state of this table.						
Using instruction of this table: Green = Standard adjustment for the choosen seat depth	Green line shows the standard setting when the adjustment of the cylinder hinge goes align with the adjustment of the back hinge. At the cylinder hinge you will find marks for the seat depth.					
Yellow= Alternative adjustment with lower starting angle	Yellow line shows the alternative setting when the cylinder hinge is adjusted to the next higher seat depth. This adjustment you can use if you need a closer starting angle.					
Blue = Alternative adjustment with higher starting angle	The blue line shows the possibility to adjust the setting to a more open angle, which can be used for users having a locked hip joint. The cylinder hinge is adjusted to the next lower seat depth.					



Netti Mobile - Combination of FREE solution and NDS-Seat plate

Seat depth in cm	Item 80172 - mounting direction	Position of 80172 at bracket at seat frame	Locking head medium - 82 mm - Item 23880	Starting angle	Angle range	Seat Type
40,00	opposite	C + D	23880	92°	40°	short
42,50	standard	E + F	23880	92°	40°	short
45,00	standard	D + E	23880	92°	40°	short
47,50	standard	C + D	23880	92°	40°	long
50,00	standard	B + C	23880	92°	40°	long

80172 - Standard mounting direction for SD 42,5 - 50,0 cm



80172 - Opposite mounting direction only für SD 40,0 cm



Holes A - F to position 80172 at seat frame bracket



A + B = 50,0 cm

B + C = 47,5 cm

C + D = 45,0 cm

D + E = 42,5 cm

E + F = 40,0 cm - only one SD with opposite mounted 80172